

Passkey III – Transponder Ignition Key



Passkey III (PK3), III + (PK3+)

Passkey III – transponder ignition key The Passkey III anti-theft system uses a transponder inside the head of the ignition key. The exciter inside the ignition lock cylinder energizes this transponder when the ignition switch is turned on. The transponder transmits a unique signature to the theft deterrent control module. If the key signature transmitted is acceptable to the theft deterrent control module, the theft deterrent control module will transmit fuel enable password to the PCM. If the fuel enable password is correct, the PCM will start the vehicle.

IMPORTANT: To perform a relearn on a Passkey III system, make sure there is a fully charged battery in the vehicle. The battery will be used for 30 minutes without the alternator available for charging. Connect a battery charger to the battery to ensure power is available while programming.

When performing this relearn, all previously learned keys will be erased. Additional keys may be relearned immediately after the first key has been learned by inserting the additional key and turning the ignition switch to on within 10 seconds of removing the previously learned key.

Directions

1. Insert a master key (black head) into the ignition switch.
2. Turn key to the “ON” position without starting the engine. Security light should turn on and stay on.
3. Wait for 10 minutes or until the security light turns off.
4. Turn key to the “OFF” position for 5 seconds.
5. Turn key to the “ON” position without starting the engine. Security light should turn on and stay on.
6. Wait for 10 minutes or until the security light turns off.
7. Turn key to the “OFF” position for 5 seconds.
8. Turn key to the “ON” position without starting the engine. Security light should turn on and stay on.
9. Wait for 10 minutes or until the security light turns off.
10. Turn key to the “OFF” position for 30 seconds. The key transponder information will be learned on the next start cycle.
11. Start the vehicle. If the vehicle starts and runs normally, the relearn is complete. If additional keys need to be relearned:
12. Turn the key to the “OFF” position.
13. Insert the next key to be learned. Turn the key to the “ON” position within 10 seconds of removing the previously used key.
14. Wait for security light to turn off. It should happen fairly quickly. You may not notice the lamp, as the transponder value will be learned immediately
15. Repeat steps 12 through 14 for any additional keys

Contact Us

If you have any further questions, please contact us:

admin@fs1inc.com

516.766.2223

www.fs1inc.com